

Ссылки на скачивание

Runtime для linux64:

https://download.mps-soft.ru/support/Updates/Installation/MasterSCADA_4D/Archive/1.3.4/RT/linux-x64/

Логин: GuestSupport

Пароль: guest

Установка mplc

1. Поместить файлы инсталлятора в каталог **/tmp**
2. Открыть терминал
3. В терминале перейти в режим суперпользователя
su-
4. Перейти в каталог с файлами инсталлятора mplc
cd /tmp
5. Назначить права администратора скрипту инсталлятора, выполнив команду **chmod u+x ./install.sh**
6. Выполнить скрипт инсталлятора, используя команду
./install.sh

```
[user@alt10 ~]$ su
Password:
[root@alt10 ~]# cd /tmp
[root@alt10 tmp]# chmod u+x ./install.sh
[root@alt10 tmp]# ./install.sh
NGINX_HTTPS=OFF
NGINX_HTTP=ON
MPLC_LOGS=OFF
Install dir: /opt/mplc4
Update configs...      OK
Stopping MasterSCADA 4D RT...  OK
Install mplc4...      OK
Install Nginx...      OK
Install dotnet runtime...      OK
Install netcore plugins...      OK
Installed successfully
mplc4.service is not a native service, redirecting to systemd-sysv-install.
Executing: /lib/systemd/systemd-sysv-install enable mplc4
```

При установке стоит учитывать, что стандартный порт Web сервера - 80, он должен быть свободен при установке без опций, в ином случае необходимо использовать указание порта, который будет использовать Web сервер

./install.sh --http-port=<port>

```
[root@alt10 tmp]# ./install.sh --http-port=8043
NGINX_HTTPS=OFF
NGINX_HTTP=ON
MPLC_LOGS=OFF
Install dir: /opt/mplc4
Update configs...      OK
Stopping MasterSCADA 4D RT...  OK
Install mplc4...      OK
Install Nginx...      OK
Install dotnet runtime...      OK
Install netcore plugins...      OK
Installed successfully
mplc4.service is not a native service, redirecting to systemd-sysv-install.
Executing: /lib/systemd/systemd-sysv-install enable mplc4
```

Запуск и остановка mplc

Запуск mplc

/etc/init.d/mplc4 start

Остановка mplc

/etc/init.d/mplc4 stop

Перезапуск mplc

/etc/init.d/mplc4 restart

```
[root@alt10 tmp]# /etc/init.d/mplc4 stop
Stopping MasterSCADA 4D RT... OK
[root@alt10 tmp]# /etc/init.d/mplc4 start
Starting MasterSCADA 4D RT... OK
[root@alt10 tmp]# /etc/init.d/mplc4 restart
Stopping MasterSCADA 4D RT... OK
Starting MasterSCADA 4D RT... OK
```

Удаление mplc

1. Открыть терминал
2. Перейти в каталог mplc: **cd /opt/mplc4**
3. Выполнить команду: **./uninstall.sh**

```
[root@alt10 ~]# cd /opt/mplc4/
[root@alt10 mplc4]# ./uninstall.sh
Stopping MasterSCADA 4D RT... OK
Remove from autostart
Remove installed files
[root@alt10 mplc4]# ls /opt
[root@alt10 mplc4]#
```